


2. Fender Studio Pro - Presonus Studio One Control Surface Documentation

Device & Plugin Control


When you select a device in the DAW it will automatically be mapped on the encoders of the MP Controller



You can also select Tracks using the Tracks button



and Devices from using the Select Device button



How to link parameters

Press the LINK button, then turn or click on an encoder and it will highlight it yellow




Move a parameter from the device or plugin you want to link and it will link the device parameter.




Press Save as default to save the mapping as a preset so the next time you select that device (any instance) it will load that preset.

Linking Buttons

Right click on a button and click Link




Move or click on the parameter you want to link and it will link it to the button



Controlling the Mixer

Click on the Mixer button and the Mixer view will open.



The top row encoders control the pan.

The 12 encoders on the left and right columns (8 on the left and 4 on the right columns) control the Send volume of the selected track.


The bottom row encoders control the volume of the track above it.

The Follow DAW button will change to the mixer page of the selected track in the DAW. If you disable it, it will not change to that page automatically.

The Fine/Fast button changes the sensitivity of the encoder controlling the volume of the track. Fast mode becomes more sensitive and travels distance fast upon turning the encoder.

Transport Control

Pressing the T button will use the encoders 28 to 32 to control the Playhead (normal mode), Playhead (fast control), Vertical Zoom level, Horizontal Zoom level and move the Loop locators left/right along the timeline



Revision #4

Created 13 June 2026 14:07:57 by Admin

Updated 13 June 2026 14:28:11 by Admin