

7. Display restarts

MP Controller display restarts constantly (flickering)

The cause for this is that the monitor does not receive enough power.

These steps may help to resolve the problem.

- use a different USB port from the computer that provides more power.
- use shorter USB cables (1m recommended cables [here in section USB-C to USB-A](#))
- use a powered USB hub
- use a [Y-cable](#) for Model 1A/1A+

For model 2A you can use the additional power port to provide more power using a wall adapter 5V/2A minimum or a power bank as explained [here](#)



For model 1A+ and model 2A If when changing the brightness or switching to a preset with high brightness (such as the FPS) the monitor restarts, it means it is not receiving enough power to support the level of brightness.

For model 1A+ you also have the option to connect a wall adapter on the internal LCD board which has an additional USB-C port. To get to that port you have to unscrew the bottom cover.

For model 1A use the [Y-cable](#) to provide additional power.

Revision #1

Created 26 April 2025 06:08:50 by Admin

Updated 26 April 2025 10:46:08 by Admin